



# Shark Cordless Pet Perfect Front Belt Replacement

Replacing the front belt to allow the vacuum to pick up debris.

Written By: Ben Dzugan



## INTRODUCTION

If you are having a problem with your device's Front Belt, Here is a Step by step guide to replace a faulty or broken Front Belt.

---



### TOOLS:

- [Phillips #2 Screwdriver](#) (1)
-

## Step 1 — Front Belt



- Remove the two 12mm screws from the front face plate with the PH2 bit from the tool kit.

## Step 2




- Once the screws are removed pull the front face plate off. This will allow access to the belt and motor.

## Step 3



- Lift the brush roller upwards towards you, and the brush roller should come out along with the belt.

## Step 4



- Remove the belt from the motor mount, and then replace with a new belt.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-08 05:22:15 AM.